

1. Add vehicle to MaptunerX
2. Synchronize with MyMaptuner
3. Connect maptuner to car, start ignition and start CloneT8 APP
4. Shut off ignition with maptuner still connected and app ON
5. Physically replace the ECU, don't forget the ground cable
6. Ignition on again and proceed with the APP by pressing Clone ECU
7. Follow instructions on the screen and start car when done



If you have any questions - please contact info@maptun.com